

Warehouse / Storage Facilities

Warehouse remote monitoring is critical to ensuring your inventory and employees remain safe from environmental factors that can cause damage or illness. Factors such as excess heat, humidity, water leaks, and more can cause damage to the goods your warehouse stores. Harsh working conditions can lead to employee illness or even injury. Your warehouse monitoring needs to protect every aspect of your business.

Room Alert provides the warehouse and distribution monitoring system you need to protect your inventory and employees. Room Alert monitors temperature, humidity, flood / water leaks, power, smoke, motion, and more to protect your inventory against loss, and your employees against injury.



Temperature & Humidity



Digital Temperature & Humidity Sensor measures temperature and humidity. Additionally, this sensor monitors dew point and heat index which indicate the “real feel” so you can keep your materials and employees safe.

Flood

Flood Sensor detects any liquid that could cause water damage or promote mold growth in your facilities. It also recognizes water leaks to improve employee safety.

Motion

Motion Sensor detects movement in your warehouse. This sensor provides security and remote management capabilities.



Air Flow

Air Flow Sensor tracks air flow in your warehouse to ensure proper ventilation for your products and employees. This increases productivity and employee safety.

Room Entry

Room Entry Sensor recognizes doors or cabinets being open. This adds a layer of security and protection.

Smoke

Smoke Sensor monitors for smoke or fire to protect your warehouse and employees.